


Before setting up, read the Safety precautions on the INSTALLATION MANUAL and INSTRUCTION BOOK.











For SETUP MANUAL and MELCloud User Manual, please go to the website below.
<http://www.melcloud.com/Support>

SETUP

 ON  Flashing



Troubleshooting

<p>ERR: OFF NET: OFF</p> 		<p>Try pairing the Wi-Fi interface with the Router.</p>
<p>ERR: Flash (Every 0.5-sec)</p> 	 <p>IP address</p>	<p>Check DHCP settings of the Router. or Check IP address settings of the Wi-Fi interface.</p>
<p>ERR: Flash (Every 1 sec)</p> 	 <p>DNS</p>	<p>Check DNS settings of the Router. or Check DNS address settings of the Wi-Fi interface.</p>
<p>ERR: Flash (Twice every 5 sec)</p> 	 <p>Internet</p>	<p>Check if the Router is connected to the Internet.</p>
<p>MODE: Flash (Once every 5 sec)</p> 	 <p>The Wi-Fi interface is set to Access point mode</p>	<p>Push MODE switch of the Wi-Fi interface for 7 seconds. Try pairing the Router again if the Wi-Fi interface is not connected.</p>